



## Hearing Protection Calculators - Introduction

This spreadsheet provides calculators for three different methods of estimating noise levels.

- **The octave-band method**  
Used if you know the noise levels in frequency bands.
- **The HML method**  
Used if you know both the A-weighted and C-weighted noise levels.
- **The SNR method**  
Used if you know the C-weighted noise levels.

Each calculator is presented on a separate 'tab' within the spreadsheet. Click on the tab to activate it. You can also move between the tabbed sheets by pressing: *Ctrl+Page Up* or *Ctrl+Page Down*.

The table on the right indicates the protection factor likely to be suitable for different levels of noise. It is based on the single number rating (SNR) value provided with a hearing protection device.

This table is intended as a guide rather than being a substitute for using one of the three methods given in this spreadsheet. In particular the table will not be appropriate if the noise is mainly low-frequency (examples where this table may not be suitable include: press shops, generators and generator test bays, plant rooms, boiler houses, concrete shaker tables, moulding presses and punch presses).

## Estimating the performance of hearing protection:

als

in the tab to go to one of the calculators.  
*Ctrl+Page Down* or using the control buttons.

Noise level dB(A)	Select a protector with an SNR of ...
85-90	20 or less
90-95	20-30
95-100	25-35
100-105	30 or more





## Hearing Protection Calculator - Octave-band method

Version 1.01 December 2020

The Octave-band method of hearing protection calculation uses:


- Octave-band attenuation and standard deviation data (available from the hearing protector supplier)
- Octave-band workplace noise levels (un-weighted values)

HEARING PROTECTOR		Make/Model:						
Frequency (Hz)	63 <i>(opt.)</i>	125	250	500	1000	2000	4000	8000
Mean attenuation (dB)								
Standard deviation (dB)								
Assumed protection (dB)								

WORKPLACE NOISE		Location/Machine:						
Frequency (Hz)	63 <i>(opt.)</i>	125	250	500	1000	2000	4000	8000
Unprotected Spectrum (dB)								
Protected Spectrum (dB)								

Unprotected noise level at the ear	$L_A$		dB(A)
Protected noise level at the ear	$L'_A$		dB(A)
HSE recommended value for the likely noise level at the ear	$L'_A + 4$		dB(A)

Protection rating:	
--------------------	--





## Hearing Protection Calculator - HML method

Version 1.01 December 2020

The HML method of hearing protection calculation uses:

- **H, M and L data**, available from the hearing protector supplier
- **A-weighted ( $L_A$  or  $L_{Aeq}$ ) and C-weighted ( $L_C$  or  $L_{Ceq}$ ) noise levels at the workplace**

**NOTE:** the  $L_{Ceq}$  value should not be confused with the peak noise level  $L_{Cpeak}$ , which is also measured in units of dB(C)

HEARING PROTECTOR			WORKPLACE NOISE		Protected noise level at the ear  $(L'_A = L_A - PNR)$ dB(A)	HSE recommended value for the likely noise level at the ear  $(L'_A + 4)$ dB(A)	Protection rating
<i>Make/Model:</i>			<i>Location/Machine:</i>				
HML values			Weighted level				
H dB	M dB	L dB	$L_A$ dB(A)	$L_C$ dB(C)			



## Hearing Protection Calculator - SNR method

Version 1.01 December 2020

The SNR method of hearing protection calculation uses:

- **SNR value**, available from the hearing protector supplier
- **C-weighted ( $L_C$  or  $L_{Ceq}$ ) noise levels at the workplace**

NOTE: the  $L_{Ceq}$  value should not be confused with the peak noise level  $L_{Cpeak}$ , which is also measured in units of dB(C)

HEARING PROTECTOR	WORKPLACE NOISE			
<i>Make/Model:</i>	<i>Location/Machine:</i>			
SNR value	C-weighted Level	Protected noise level at the ear	HSE recommended value for the likely noise level at the ear	Protection rating
<b>SNR</b> dB	$L_C$ dB(C)	$(L'_A = L_C - SNR)$ dB	$(L'_A + 4)$ dB(A)	